



AMP Models:

There are pre-amp models you can select. *More amp models will be added with the future updates.*



Reset: Resets the selected IR file to factory settings.



Save: Save your IR files to your computer



Load: Load any of your favorite IR file* to the device.

The Impulse Response (IR) file must be:

24-bit, Stereo, 48 KHz, WAV

If your file specs are different, you can use the **NUX File Converter** software available to download on nuxefx.com for free

Blend: Adjusts overdrive signal mix with the dry signal between 50% and 100%

Drive: Adjusts the overdrive level (can be activated with DRIVE footswitch)

Volume: Adjusts the output volume

Noise Gate: Push and hold the Drive footswitch for 1.5 seconds, the green LED light will start to blink. Now you can control the noise gate on the software. When you turn the Threshold to 0, noise gate will be OFF.

Decay: Adjusts the speed of the noise gate

Threshold: Adjusts the gate level

3-Band EQ controls and Mid-Freq Selector

Bass: Adjusts the low frequency level

Middle: Adjusts the selected middle frequency level

Freq: You can choose any frequency to adjust from low mid 150 Hz to high mid 940 Hz

Treble: Adjusts the high frequency

Preamp ON/OFF

MIDI Options: You can control the software with the MIDI controller device


USB Audio / Routing: USB audio streaming options.



Output Level Display: It shows the signal output level.

Speaker Cabinet Simulation ON/OFF

Cabinet List: You can choose a built-in or loaded cabinet models by clicking on it



Graphic EQ display: It shows the frequency curves of the selected IR file. You can understand the sound characteristic of the selected speaker cabinet.

